

# **USER MANUAL**



# **Online UPS: Challenger Series**

Stand Alone (SA) 220 VAC

Capacity: 6 KVA ~ 10 KVA

REVISION	DESCRIPTION	DATE
Rev. 1.1	Formal Release	2016/01/27











Danger: For your safety

Improper use on this equipment can lead to an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Warning: Caution

Unsafe practices that could endanger health, safety and cause financial damage.



Important

Any important technical and operating information on the equipment, should not neglected.



Annotation

Sy-G reserves the right to alter the features of its products without prior notice.







## **CONTENTS**

1. Safety Warning	2
1.1. Transportation	2
1.2. Preparation	2
1.3. Installation	2
1.4. Connection warnings	3
1.5. Operation	4
1.6. Standards	4
2. Installation and Setup	5
2.1. Unpacking and Inspection	5
2.2. Rear Panel View	5
2.3. Single UPS Installation	7
2.4. Software Installation	9
3. Operations	10
3.1. Button Operation	10
3.2. LED Indicators	10
3.3. LCD Panel	11
3.4. Audible Alarm	12
3.5. Single UPS Operation	13
3.5.1. Turn on the UPS (in AC mode)	13
3.5.2. Turn on the UPS (in Battery mode)	13
3.5.3. Connect Devices to UPS	14
3.5.4. Charge the Batteries	14
3.5.5. Battery mode Operation	14
3.5.6. Turn off the UPS (in AC mode)	15
3.5.7. Turn off the UPS (in Battery mode)	15
3.5.8. Mute the Buzzer	15
3.5.9. Operation in Warning Status	15
3.5.10. Operation in Fault mode	
3.6. Abbreviation Meaning in LCD	
3.7. LCD Setting	
3.8. Operating Mode/Status Description	
3.9. Faults Reference Code	
3.10. Warning indicator	
4. Troubleshooting	
5. Storage and Maintenance	
6. Technical Specifications	



## 1. Safety Warning

Please read carefully the following user manual and the safety instructions before installing the unit or using the unit!

#### 1.1. **Transportation**

Please transport the UPS system only in the original package to protect against shock and impact.

The UPS must be stored in the room where it is ventilated and dry.

## 1.2. Preparation

Condensation may occur if the UPS system is moved directly from cold to warm environment.

The UPS system must be absolutely dry before being installed.

## PLEASE ALLOW AT LEAST TWO HOURS FOR THE UPS SYSTEM TO ACCLIMATE THE ENVIRONMENT.

- **Do not** install the UPS system near water or in moist environments.
- Do not install the UPS system where it would be exposed to direct sunlight or near heater.
- **Do not** block ventilation holes in the UPS housing.

### 1.3. Installation

- Do not connect appliances or devices which would overload the UPS system (e.g. big motor-type equipment) to the UPS output sockets or terminal.
- Place cables in such a way that no one can step on or trip over them.
- Do not block air vents in the housing of UPS. The UPS must be installed in a location with good ventilation. Ensure enough space on each side for ventilation.
- UPS has provided earthed terminal, in the final installed system configuration, equipotential earth bonding to the external UPS battery cabinets.
- The UPS can be installed only by qualified maintenance personnel.
- An appropriate disconnect device as short-circuit backup protection should be provided in the building wiring installation.








- An integral single emergency switching device which prevents further supply 0 to the load by the UPS in any mode of operation should be provided in the building wiring installation.
- Connect the earth before connecting to the building wiring terminal.
- Installation and Wiring must be performed in accordance with the local electrical laws and regulations.

#### **Connection Warnings** 1.4.

There is no standard backfeed protection inside of the UPS. Please isolate the UPS before working according to Diagram 1. The isolation device must be able to carry the UPS input current.



- This UPS should be connected with TN earthing system.
- The power supply for this unit must be single-phase rated in accordance with the equipment nameplate. It also must be suitably grounded.
- Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.
- Connect your UPS power module's grounding terminal to a grounding electrode conductor.
- The UPS is connected to a DC energy source (battery). The output terminals may be live when the UPS is not connected to an AC supply



### **BEFORE WORKIN ON THIS CIRCUIT**

- Isolate Uninterruptible Power System (UPS).
- The check for Hazardous voltage between all terminals including the protective earth.



RISK OF VOLTAGE BACKFEED.

#### **1.5**. **Operation**

- Do not disconnect the mains cable on the UPS system or the building wiring outlet (shockproof socket outlet) during operations since this would cancel the protective earthing of the UPS system and of all connected loads.
- The UPS system features its own, internal current source (batteries). The UPS output sockets or output terminals block may be electrically live even if the UPS system is not connected to the building wiring outlet.
- In order to fully disconnect the UPS system, first press the OFF button to disconnect the mains (commercial power).
- Ensure that no liquid or other foreign objects can enter into the UPS system.
- The UPS can be operated by any individuals with no previous experience.

## 1.6. Standards

Safety		
IEC/EN 62040-1		
EMI		
Conducted EmissionIEC/EN 62040-2	Category C3	
Radiated EmissionIEC/EN 62040-2	Category C3	
EMS		
ESDIEC/EN 61000-4-2	Level 4	
RSIEC/EN 61000-4-3	Level 3	
EFTIEC/EN 61000-4-4	Level 4	
SURGEIEC/EN 61000-4-5	Level 4	
CSIEC/EN 61000-4-6	Level 3	
Power-frequency Magnetic fieldIEC/EN 61000-4-8	Level 4	
Low Frequency SignalsIEC/EN 61000-2-2		
<b>Warning:</b> This is a product for commercial and industrial application in the second environment-installation restrictions or additional measures may be needed to prevent disturbances.		











## 2. Installation and Setup

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. Please keep the original package in a safe place for future use.

Parallel function is also available for these two types and related installation and operation of Parallel function will be described in detail in the following content.


#### 2.1. Unpacking and Inspection


Unpack the package and check the package contents. The shipping package contains:

- One UPS.
- One user manual.
- One monitoring software CD.
- o One RS-232 cable (option).
- o One USB cable.
- One battery cable (option).


NOTE: Before installation, please inspect the unit. Be sure that nothing inside the package is damaged during transportation. Do not turn on the unit and notify the carrier and dealer immediately if there is any damage or lacking of some parts. Please keep the original package in a safe place for future use.


#### 2.2. **Rear Panel View**











## **Description UPS**

- External battery connector.
- RS-232 communication port.
- Intelligent slot.
- USB communication port.
- Emergency power off function connector (EPO connector).
- Cooling fan.

- Input circuit breaker.
- Input/Output terminals.
- Maintenance bypass switch (option).
- Output terminal.
- Ground.
- Input terminal.



#### 2.3. **Single UPS Installation**

Installation and wiring must be performed in accordance with the local electric laws/regulations and execute the following instructions by professional personnel.

1) Make sure the mains wire and breakers in the building are enough for the rated capacity of UPS to avoid the hazards of electric shock or fire.

NOTE: Do not use the wall receptacle as the input power source for the UPS, as its rated current is less than the UPS' s maximum input current. Otherwise the receptacle may be burned and destroyed.

- 2) Switch off the mains switch in the building before installation.
- 3) Turn off all the connected devices before connecting to the UPS.
- 4) Prepare wires based on the following table:

MODEL	WIRING SPEC (AWG)				
	INPUT	OUTPUT	BATTERY	GROUND	
6K	10	12		12	
6KL	10	12	12	12	
10K	8	8		8	
10KL	8	8	8	8	


NOTE 1: It is recommended to use suitable wire in above table or thicker for safety and efficiency.

NOTE 2: The selections for color of wires should be followed by the local electrical laws and regulations.

5) Remove the terminal block cover on the rear panel of UPS. Then connect the wires according to the following terminal block diagrams: (Connect the earth wire first when making wire connection. Disconnect the earth wire last when making wire disconnection!)

Page | 7





**NOTE 1:** Make sure that the wires are connected tightly with the terminals.

NOTE 2: Please install the output breaker between the output terminal and the load, and the breaker should be qualified with leakage current protective function if necessary.

6) Put the terminal block cover back to the rear panel of the UPS.



## Warning: (Only for standard model)

- Make sure the UPS is not turned on before installation. The UPS should not be turned on during wiring connection.
- o Do not try to modify the standard model to the long-run model. Particularly, do not try to connect the standard internal battery to the external battery. The battery type and voltage may be different. If you connect them together, it maybe causes the hazard of electric shock or fire!



## Warning: (Only for long-run model)

Make sure a DC breaker or other protection device between UPS and external battery pack is installed. IF not, please install it carefully. Switch OFF the battery breaker before installation.



## Warning:

For standard battery pack, there is one DC breaker to disconnect the battery pack and the UPS. But for other external battery pack, make sure a DC breaker or other protection device between UPS and external battery pack is installed. If not, please install it carefully. Switch off the battery breaker before installation.



**NOTE:** Set the battery pack breaker in "OFF" position and then install the battery pack.

- Pay highly attention to the polarity marking on external battery terminal block, and make sure the correct battery polarity is connected. Wrong connection may cause permanent damage of the UPS.
- Make sure the protective earth ground wiring is correct. The wire current spec, color, position, connection and conductance reliability should be checked carefully.
- Make sure the utility input & output wiring is correct. The wire current spec, color, position, connection and conductance reliability should be checked carefully. Make sure the L/N site is correct, not reverse and short-circuited.

#### 2.4. **Software Installation**

For optimal computer system protection, install UPS monitoring software to fully configure UPS shutdown. Use supplied RS-232 or USB communication cable to connect RS-232/USB port of UPS and RS-232/USB port of PC. Then, follow below steps to install monitoring software.

- 1. Insert the included installation CD into CD-ROM drive and then follow the onscreen instructions to proceed software installation. If there no screen shows 1 minute after inserting the CD, please execute setup.exe file for initiating software installation.
- 2. Follow the on-screen instructions to install the software.
- 3. When your computer restarts, the monitoring software will appear as an orange plug icon located in the system tray, near the clock.






## 3. Operations

## 3.1. Button Operation

BUTTON	FUNCTION
ON/Enter Potter	<ul> <li>TURN ON the UPS: Press and hold the button more than 1s to turn on the UPS.</li> </ul>
ON/Enter Button	<ul> <li>Enter Key: Press this button to confirm the selection in setting menu.</li> </ul>
OFF/ESC Button	<ul> <li>TURN OFF the UPS: Press and hold the button more than 1s to turn off the UPS.</li> </ul>
	o Esc key: Press this button to return to last menu in setting menu.
Test/Up Button	<ul> <li>Battery test: Press and hold the button more than 1s to test the battery while in AC mode, or CVCF mode [1].</li> </ul>
	<ul> <li>UP key: Press this button to display next selection in setting menu.</li> </ul>
Mute/Down Button	<ul> <li>Mute the alarm: Press and hold the button more than 1s to mute the buzzer. Please refer to section 3.5.9 for details.</li> <li>Down key: Press this button to display previous selection in setting menu.</li> </ul>
Test/Up + Mute/Down Button	Press and hold the two buttons simultaneous more than 1s to enter/escape the setting menu.

<sup>[1]</sup> CVCF mode means converter mode.

## 3.2. LED Indicators




LED MODE	BYPASS	LINE	BATTERY	FAULT
UPS Startup	•	•	•	•
Bypass mode	•	0	0	0
AC mode	0	•	0	0
Battery mode	0	0	•	0
CVCF mode	0	•	0	0
Battery Test	•	•	•	0
Fault	0	0	0	•

Note: ● means LED is lighting, and ○ means LED is faded.



#### 3.3. **LCD Panel**



DISPLAY	FUNCTION
REMAINING BACKUP TI	ME INFORMATION
	Indicates the remaining backup time in pie chart.
H <b>88</b>	Indicates the remaining backup time in numbers. H: hours, M: minute, S: second
FAULT INFORMATION	
<b>⟨⟨</b> \į	Indicates that the warning and fault occurs.
8.8	Indicates the warning and fault codes, and the codes are listed in details in 3-9 section.
MUTE OPERATION	
<b>■</b> ×	Indicates that the UPS alarm is disabled.
OUTPUT & BATTERY VO	DLTAGE INFORMATION
888 Vac Vdc Hz	Indicates the output voltage, frequency or battery voltage. Vac: output voltage, Vdc: battery voltage, Hz: frequency
LOAD INFORMATION	
© 1	Indicates the load level by 0-25%, 26-50%, 51-75%, and 76-100%.
OVER LOAD	Indicates overload.
SHORT	Indicates the load or the UPS output is short circuit.
MODE OPERATION INFO	DRMATION
<b>⊘</b>	Indicates the UPS connects to the mains.
( <del>+</del> -	Indicates the battery is working.
BYPASS	Indicates the bypass circuit is working.



ECO	Indicates the ECO mode is enabled.			
==/~	Indicates the Inverter circuit is working.			
0/P	Indicates the output is working.			
BATTERY INFORMATION				
	Indicates the Battery level by 0-25%, 26-50%, 51-75%, and 76-100%.			
BATT. FAULT	Indicates the battery is fault.			
LOW BATT.	Indicates low battery level and low battery voltage.			
INPUT & BATTERY VOLT	INPUT & BATTERY VOLTAGE INFORMATION			
888 Vac	Indicates the input voltage or frequency or battery voltage.  Vac: Input voltage, Vdc: battery voltage, Hz: input frequency			

## 3.4. Audible Alarm

DESCRIPTION	BUZZER STATUS	MUTED
UPS status		
Bypass mode	Beeping once every 2 minutes	
Battery mode	Beeping once every 4 seconds	Yes
Fault mode	Beeping continuously	
Warning		
Overload	Beeping twice every second	
Low battery		
Battery unconnected		
Over charge		
EPO enable		No
Fan failure/Over temperature	Beeping once every second	NO
Charge failure		
Overload 3 times in 30 min		
EPO status		
Cover of maintain switch is open		
Fault		
Bus start failure		
Bus over	Beeping continuously	Yes
Bus under		





Bus unbalance		
Inverter soft start failure		
High Inverter voltage		
Low Inverter voltage	Beeping continuously	Yes
Inverter output short circuited		
Over temperature		
Overload		

#### 3.5. **Single UPS Operation**

### 3.5.1. Turn on the UPS with utility power supply (in AC mode)

1) After power supply is connected correctly, set the breaker of the battery pack at "ON" position (the step only available for long-run model). Then set the input breaker at "ON" position. At this time the fan is running and the UPS enter to power on mode for initialization, several seconds later, UPS operates in Bypass mode and supplies power to the loads via the bypass.


**NOTE:** When UPS is in Bypass mode, the output voltage will directly power from utility after you switch on the input breaker. In Bypass mode, the load is not protected by UPS. To protect your precious devices, you should turn on the UPS. Refer to next step.

- 2) Press and hold the "ON" button for 0.5s to turn on the UPS and the buzzer will beep once.
- 3) A few seconds later, the UPS will enter to AC mode. If the utility power is abnormal, the UPS will operate in Battery mode without interruption.

**NOTE:** When the UPS is running out battery, it will shut down automatically at Battery mode. When the utility power is restored, the UPS will auto restart in AC mode.

### 3.5.2. Turn on the UPS without utility power supply (in Battery mode)

- 1) Make sure that the breaker of the battery pack is at "ON" position (only for long-run model).
- 2) Press the "ON" button to set up the power supply for the UPS, UPS will enter to power on mode. After initialization UPS will enter to No Output mode, then Press and hold the "ON" button for 1s to turn on the UPS, and the buzzer will beep once.
- 3) A few seconds later, the UPS will be turned on and enter to Battery mode.







### 3.5.3. Connect Devices to UPS

After the UPS is turned on, you can connect devices to the UPS.

- 1) Switch on the devices one by one and it will display total load level in LCD panel.
- 2) If it is necessary to connect the inductive loads such as a printer, the in-rush current should be calculated carefully to see if it meets the capacity of the UPS, because the power consumption of this kind of loads is too big.
- 3) If the UPS is overload, the buzzer will beep twice every second.
- 4) When the UPS is overload, please remove some loads immediately. It is recommended to have the total loads connected to the UPS less than 80% of its nominal power capacity to prevent overload for system safety.
- 5) If the overload time is over acceptable time listed in spec at AC mode, the UPS will automatically transfer to bypass mode. After the overload is removed, it will return to AC mode. If the overload occurs 3 times in half hour, the UPS will be locked in Bypass mode. UPS can transfer to Line mode only by manual restart. At this time, if bypass is enabled, the UPS will power to the load via bypass. If bypass function is disabled or the input power is not within bypass acceptable range, it will cut off output directly.

## 3.5.4. Charge The Batteries

- 1) After the UPS is connected to the utility power and working on the AC mode, the charger will charge the batteries automatically except in Battery mode or during battery self-test.
- 2) Suggest charging batteries at least 10 hours before use. Otherwise, the backup time may be shorter than expected time. The charging current can be changed from 1A to 6A via LCD or software. Please

make sure that the charging current is suitable to battery specification.

### 3.5.5. Battery Mode Operation

1) When the UPS is in Battery mode, the buzzer will beep according to different battery capacity. If the battery capacity is more than 25%, the buzzer will beep once every 4 seconds; If the battery voltage drops to the alarm level, the buzzer will beep quickly (once every sec) to remind users that the battery is at low level and the UPS will shut down automatically soon. Users could switch off some non-critical loads to disable the shutdown alarm and prolong the backup time. If there is no more load to be switched off at that time, you have to shut down all loads as soon as possible to protect the devices or save data. Otherwise, there is a risk of data loss or load failure.



- 2) In Battery mode, if buzzer sound annoys, users can press the Mute button to disable the buzzer.
- 3) The backup time of the long-run model depends on the external battery capacity.
- 4) The backup time may vary from different environment temperature and load type.
- 5) When setting backup time for 16.5 hours (default value from LCD panel), after discharging 16.5 hours, UPS will shut down automatically to protect the battery. This battery discharge protection can be enabled or disabled through LCD panel control. (Refer to 3-7 LCD setting section).

## 3.5.6. Turn off the UPS with utility power supply in AC mode

- 1) Turn off the inverter of the UPS by pressing "OFF" button for at least 1s, and then the buzzer will beep once. The UPS will turn into Bypass mode.
  - **NOTE 1:** If the UPS has been set to enable the bypass output, it will bypass voltage from utility power to output terminal even though you have turned off the UPS (inverter).
  - **NOTE 2:** After turning off the UPS, please be aware that the UPS is working at Bypass mode and there is risk of power loss for connected devices.
- 2) In Bypass mode, output voltage of the UPS is still present. In order to cut off the output, switch off the input breaker. A few seconds later, there is no display shown on the display panel and UPS is complete off.

## 3.5.7. Turn off the UPS without utility power supply in Battery mode

- 1) Turn off the UPS by pressing "OFF" button for at least 1s, and then the buzzer will beep once.
- 2) Then UPS will cut off power to output and there is no display shown on the display panel.

### 3.5.8. Mute The Buzzer

- 1) To mute the buzzer, please press the "Mute" button for at least 1s. If you press it again after the buzzer is muted, the buzzer will beep again.
- 2) Some warning alarms can't be muted unless the error is fixed. Please refer to section 3.3 for the details.

### 3.5.9. Operation In Warning Status

Page | 15



- 1) When Fault LED flashes and the buzzer beeps once every second, it means that there are some problems for UPS operation. Users can get the warning code from LCD panel. Please check trouble shooting table in chapter 4 for details.
- 2) Some warning alarms can't be muted unless the error is fixed. Please refer to section 3.3 for the details.

#### 3.5.10. **Operation In Fault Mode**

- 1) When Fault LED illuminates and the buzzer beeps continuously, it means that there is a fatal error in the UPS. Users can get the fault code from display panel. Please check trouble shooting table in chapter 4 for details.
- 2) Please check the loads, wiring, ventilation, utility, battery and so on after the fault occurs. Do not try to turn on the UPS again before solving the problems. If the problems can' t be fixed, please contact the distributor or service people immediately.
- 3) For emergency case, please cut off the connection from utility, external battery, and output immediately to avoid more risk or danger.


## 3.6. Abbreviation Meaning in LCD Display

ABBREVIATION	DISPLAY CONTENT	MEANING
ENA	ENR	Enable
DIS	d1 5	Disable
AT	AF O	Auto
BAT	68E	Battery
NC	NEF	Normal mode (not CVCF mode)
CF	ΕF	CVCF mode
SUB & SU	506	Subtract
ADD & AD	Rdd	Add
ON	OΠ	On
OFF	OFF	Off
FBD	Fbd	Not allowed
OPN	OPN	Allow
RES	res	Reserved

Page | 16



## 3.7. LCD Setting



There are three parameters to set up the UPS.

Parameter 1: It is for program alternatives or setting options. Refer to below table. Parameter 2 and Parameter 3: Are the setting options or values for each program.

## **Programs available list for PARAMETER 1.**

CODE	DESCRIPTION	Bypass	AC	CVCF	Battery	Battery Test	
01	Output voltage	Y					
02	Output frequency	Y					
03	Voltage range for bypass	Y					
04	Frequency range for bypass	Y					
05	Reserved			N			
06	Reserved			N			
07	7 Reserved		N				
08	Bypass mode setting	Y	Υ				
09	Battery backup time setting	Y	Υ	Y	Υ	Y	
10	10 Reserved		N				
11	11 Reserved		N				
12	Reserved			N			
13	Battery voltage Calibration	Y	Υ	Υ	Υ	Υ	
14	4 Reserved			N			
15	Inverter voltage Calibration		Υ	Υ	Υ		
16	Floating charger voltage adjustment	Y	Υ	Υ	Υ	Υ	
17	Constant charger voltage adjustment	Y	Υ	Y	Υ	Y	



18	Charger maximum current setting	Y	Y	Y	Y	Υ
19	Battery capacity and groups setting	Y	Y	Y	Y	Y
20	Backup time calibration	Y	Y	Y	Y	Y

**Y** means that this program can be set in this mode.


## **01:** Output voltage setting.

INTERFACE	SETTING
0 I*	Parameter 3: Output voltage
<b>₽ 3 0</b> Vac	For 208/220/230/240 VAC models, you may choose the following output voltage:
	208: presents output voltage is 208Vac.
	220: presents output voltage is 220Vac.
	230: presents output voltage is 230Vac.
	240: presents output voltage is 240Vac.

## **02:** Output Frequency.

INTERFACE	SETTING
60 Hz, CVCF mode  02"  50 Hz, Normal mode  02"  50.0 n; 0CF	Parameter 2: Output Frequency  Setting the output frequency. You may choose following three options in parameter 2:  50.0Hz: The output frequency is setting for 50.0Hz. 60.0Hz: The output frequency is setting for 60.0Hz. ATO: If selected, output frequency will be decided according to the latest normal utility frequency. If it is from 46Hz to 54Hz, the output frequency will be 50.0Hz. If it is from 56Hz to 64Hz, the output frequency will be 60.0Hz. AT is default setting.  Parameter 3: Frequency mode  Setting output frequency at CVCF mode or not CVCF mode. You may choose following two options in parameter 3:  CF: Setting UPS to CVCF mode. If selected, the output frequency will be fixed at 50Hz or 60Hz according to setting in parameter 2. The input frequency could be from 46Hz to 64Hz.  NCF: Setting UPS to normal mode (not CVCF mode). If selected, the output frequency with synchronize with the input frequency within 46~54 Hz at 50Hz or within 56~64 Hz at 60Hz according to setting in parameter 2.





If 50 Hz selected in parameter 2, UPS will transfer to battery mode when input frequency is not within 46~54 Hz. If 60Hz selected in parameter 2, UPS will transfer to battery mode when input frequency is not within 56~64

 $^{\text{[1]}}$  If Parameter 2 is ATO, the Parameter 3 will show the current frequency.

### **03:** Voltage range for bypass.

INTERFACE	SETTING
03« 176 *** 264 ***	Parameter 2: Set the acceptable low voltage range for bypass. Setting range is from 110V to 209V.  (Default value is 110V).  Parameter 3: Set the acceptable high voltage range for bypass. Setting range is from 231V to 276V.  (Default value is 264V).

**04:** Frequency range for bypass.

INTERFACE	SETTING
04« 46.8 <sub>**</sub> 53.8 <sub>**</sub>	Parameter 2: Set the acceptable low frequency for bypass.  50Hz: Setting range is from 46.0Hz to 49.0Hz. 60Hz: Setting range is from 56.0Hz to 59.0Hz. (Default value is 46.0Hz/56.0Hz).  Parameter 3: Set the acceptable high frequency for bypass.  50Hz: Setting range is from 51.0Hz to 54.0Hz. 60Hz: Setting range is from 61.0Hz to 64.0Hz. (Default value is 54.0Hz/64.0Hz).

### 05: Reserved.

INTERFACE	SETTING
CS" FES FES	Reserved



## **06:** Reserved.

INTERFACE	SETTING
05« res res	Reserved

## **07:** Reserved.

INTERFACE	SETTING
O7« res res	Reserved

## **08:** Bypass mode setting.

INTERFACE	SETTING
OPN ENR	<b>Parameter 2</b> , please press "Enter" key first. Then, you have the following options:
	<b>OP:</b> Bypass allowed. When selected, UPS will run at Bypass mode depending on bypass enabled/disabled setting.
	<b>FBD:</b> Bypass not allowed. When selected, it's not allowed for running in Bypass mode under any situations.
	Parameter 3:
	<b>ENA:</b> Bypass enabled. When selected, Bypass mode is activated.
	<b>DIS:</b> Bypass disabled. When selected, automatic bypass is acceptable, but manual bypass is not allowed. Manual bypass means users manually operate UPS for Bypass mode. For example, pressing <b>OFF button</b> in AC mode to
	turn into Bypass mode.



## **09:** Battery backup time setting.

INTERFACE	SETTING
990	Parameter 3:  000~999: Set the maximum backup time from 0min to 999min. UPS will shut down to protect battery after backup time arrives.  DIS: Disable battery discharge protection and backup time will depend on battery capacity.

## 10: Reserved.

INTERFACE	SETTING
IO«   res res	Reserved

### 11: Reserved.

INTERFACE	SETTING
TES TES	Reserved

## 12: Reserved.

INTERFACE	SETTING	
IZ" FES FES	Reserved	



## **13:** Battery voltage calibration.

INTERFACE	SETTING	
13« Rdd 0 l8	Parameter 2: Select "Add" or "Sub" function to calibrate battery voltage to real figure.  Parameter 3: The voltage setting range is from 0V to 5.7V.  (Default value is 0V).	

### 14: Reserved.

INTERFACE	SETTING
IY« res res	Reserved

## **15:** Inverter voltage calibration.

INTERFACE	SETTING	
15«   Rdd 0 l8 ***	Parameter 2: You may choose "Add" or "Sub" function to inverter voltage.  Parameter 3: The voltage setting range is from 0V to 6.4V.  (Default value is 0V).	

## **16:** Floating charger voltage adjustment.

INTERFACE	SETTING	
16«   844 02.5 vac	Parameter 2: You may choose "Add" or "Sub" to adjust floating charger voltage.  Parameter 3: The voltage setting range is from 0V to 8V.	
	(Default value is 0V).	



## **17:** Constant charger voltage adjustment.

INTERFACE	SETTING	
17« Rdd 02.6 vac ©	Parameter 2: You may choose "Add" or "Sub" to constant charger voltage.  Parameter 3: The voltage setting range is from 0V to 4V.  (Default value is 0V).	

## **18:** Maximum charger current setting.

INTERFACE	SETTING	
18" 40 Q	Parameter 3: The maximum charging current could be adjusted; the available options are 1A, 2A, 4A.  (Default value is 4A for long run model and 1A for standard model).	

## **19:** Battery capacity and groups setting.

INTERFACE	SETTING	
19« 009 00 1 Q	Parameter 2: Set the battery capacity such as 7AH, 9AH, 10AH, 12AH, 17AH, 26AH, 40AH, 65AH, 100AH and so on. (Default value is 9AH).  Parameter 3: Set battery group range from 1 to 6. These parameters are for the battery backup time calculation.	

## **20:** Backup time calibration.

INTERFACE	SETTING	
20° UO Q	Parameter 3: Calibrate the displayed backup time by adjusting this multiplier factor. The formulation is listed below:  Displayed backup time=Original calculated backup time x Multiplier factor.  The default value of multiplier factor is 1.0 and the setting range is from 0.5 to 2.	



#### 3.8. **Operating Mode/Status Description**

This section describes the mode and operating status of the UPS, read carefully before making any configuration.

Operating Mode/Status				
	Description	When the input voltage is within acceptable range, UPS will provide pure and stable AC power to output. The UPS will also charge the battery at AC mode.		
AC mode	LCD display	SOO HZ SOO HZ OUTPUT O THE		
	Description	When input frequency is within 46 to 64Hz, the UPS can be set at a constant output frequency, 50 Hz or 60 Hz. The UPS will still charge battery under this mode.		
CVCF mode	LCD display	EF    CF   SC.3   SO.0       H		
	Description	When the input voltage is beyond the acceptable range or power failure UPS will backup power from battery and alarm will beep every 4 seconds.		
Battery mode	LCD display	229 vdc 220 Vac Q Vdc SOO Mz Q A		
Bypass mode	Description	When input voltage is within acceptable range and bypass is enabled, turn off the UPS and it will enter Bypass mode. Alarm beeps every two minutes.		



Bypass mode	LCD display	SOO HZ Y99 HZ  INPUT  OUTPUT  OUTPUT
Battery	Description	When UPS is in AC mode or CVCF mode, press "Test" key for more than 1s. Then the UPS will beep once and start "Battery Test". The line between I/P and inverter icons will blink to remind users. This operation is used to check the battery status.
test	LCD display	239 vdc 220 vac    1
	Description	When UPS has fault happened, it will display fault messages in LCD Panel.
Fault status	LCD display	43  Vac ODD Vac  VER LOAD  INPUT  INPUT  OUTPUT  OU

## 3.9. Faults Reference Code

FAULT EVENT	FAULT CODE	ICON	FAULT EVENT	FAULT CODE	ICON
Bus start failure	01	None	Low Inverter voltage	13	None
Bus over	02	None	Inverter output short circuited	14	SHORT
Bus under	03	None	Battery SCR short circuited	21	None
Bus unbalance	04	None	Over temperature	41	None
Inverter soft start failure	11	None	Overload	43	OVER LOAD
High Inverter voltage	12	None			





## 3.10. Warning Indicator

WARNING	ICON (FLASHING)	ALARM
Battery low	! LOW BATT.	Beeping every second
Overload	OVER LOAD	Beeping twice every second
Battery unconnected	BATT. FAULT	Beeping every second
Over charge		Beeping every second
EPO enable	<u> </u>	Beeping every second
Over temperature	<u> = </u>	Beeping every second
Charger failure	A E	Beeping every second
Overload 3 times in 30 min.	$\triangle$	Beeping every second

Page | 26



## 4. Troubleshooting

If the UPS system does not operate correctly, solve the problem by using the table below:

SYMPTOM	POSSIBLE CAUSE	REMEDY	
No indication and alarm in the front display panel even though the mains is normal.	The AC input power is not connected well.	Check if input cable firmly connected to the mains.	
The icon And the warning code <b>EP</b> flash on LCD display and alarm beeps every second.	EPO function is enabled.	Set the circuit in closed position to disable EPO function.	
The icon And BATT.FAULT flash on LCD display and alarm beeps every second.	The external or internal battery is incorrectly connected.	Check if all batteries are connected well.	
The icon and over LOAD flash on LCD display and alarm beeps twice every second.	UPS is overload.	Remove excess loads from UPS output.	
	UPS is overloaded. Devices connected to the UPS are fed directly by the electrical network via the Bypass.	Remove excess loads from UPS output.	
	After repetitive overloads, the UPS is locked in the Bypass mode. Connected devices are fed directly by the mains.	Remove excess loads from UPS output first. Then shut down the UPS and restart it.	
Fault code is shown as 43. The icon lights on LCD display and alarm beeps continuously.	UPS is overload too long and becomes fault. Then UPS shut down automatically.	Remove excess loads from UPS output and restart it.	
Fault code is shown as 14, the icon short lights on LCD display, and alarm beeps continuously.	The UPS shut down automatically because short circuit occurs on the UPS output.	Check output wiring and if connected devices are in short circuit status.	
Other fault codes are shown on LCD display and alarm beeps continuously.	A UPS internal fault has occurred.	Contact your dealer.	
Battery backup time is shorter than nominal value	Batteries are not fully charged	Charge the batteries for at least 7 hours and then check capacity. If the problem still persists, consult your dealer.	

Page | 27



Battery backup time is shorter than nominal value	Batteries defect	Contact your dealer to replace the battery.		
The icon And Implementation and the icon LCD display and alarm beeps every second.	The UPS temperature is too high.	Check fans and notify dealer.		



## 5. Storage and Maintenance

### **Storage**

Before storing, charge the UPS at least 7 hours. Store the UPS covered and upright in a cool, dry location. During storage, recharge the battery in accordance with the following table:

STORAGE TEMPERATURE	RECHARGE FREQUENCY	CHARGING DURATION	
-25°C - 40°C	Every 3 months	1-2 hours	
40°C - 45°C	Every 2 months	1-2 hours	

#### Maintenance



The UPS system operates with hazardous voltages. Repairs may be carried out only by qualified maintenance personnel.



Even after the unit is disconnected from the mains, components inside the UPS system are still connected to the battery packs which are potentially dangerous.



Before carrying out any kind of service and/or maintenance, disconnect the batteries and verify that no current is present and no hazardous voltage exists in the terminals of high capability capacitor such as BUS-capacitors.



Only persons are adequately familiar with batteries and with the required precautionary measures may replace batteries and supervise operations. Unauthorized persons must be kept well away from the batteries.



Verify that no voltage between the battery terminals and the ground is present before maintenance or repair. In this product, the battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground.

Batteries may cause electric shock and have a high short-circuit current. Please remove all wristwatches, rings and other metal personal objects before maintenance or repair, and only use tools with insulated grips and handles for maintaining or repairing.







When replace the batteries, install the same number and same type of batteries.



Do not attempt to dispose of batteries by burning them. This could cause battery explosion. The batteries must be rightly deposed according to local regulation.



Do not open or destroy batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.



Please replace the fuse only with the same type and amperage in order to avoid fire hazards.



Do not disassemble the UPS system.



## **6.** Technical Specifications

	MODEL	6 K	(VA	10 KVA		
Phase	MODEL	0.1			WA	
Capacity [1	1]	6000 VA	Single phase with ground 6000 VA / 5400 W 10000 VA / 9000 W			
INPUT						
Nominal Vo	oltage		208/220/23	30/240 VAC		
				© 50% Load		
Voltage Ra	ange			@ 100% Load		
Frequency	Range		46 - 54 Hz or 56 -			
Power Fac				oltage (100% load)		
Rectifier		IGBT				
OUTPUT						
Output Volt	tage		208 [1]/220/2	230/240 VAC		
Voltage Re	egulation		±	1%		
Frequency	Range (Synchronized Range)		46 - 54 Hz or 56 -	64 Hz (Selectable)		
Frequency	Range (Batt. Mode)		50 Hz or 60	Hz ± 0.1 Hz		
Current Cr	est Ratio		3	:1		
Harmonic I	Distortion (THDv)	≤	3% THD (Linear Load),	≤ 5% THD (Non-linear Loa	id)	
Transfer Ti	ime		Zero (AC to DC) ; Zer	ro (Inverter to Bypass)		
Waveform			Pure Si	ne Wave		
<b>EFFICIEN</b>	CY					
AC Mode		92	2%	93	3%	
Battery Mo	ode	90	)%	91	1%	
BATTERY						
	Battery Type		12V	/9 Ah		
01	Numbers	16	20	16	20	
Standard	Typical Recharge Time		9 hours recover	to 90% capacity		
Model	Charging Current (max.)		1A / 2 A (	Adjustable)		
	Charging Voltage	218.4 VDC ± 1%	273 VDC ± 1%	218.4 VDC ± 1%	273 VDC ± 1%	
	Battery Type		Depending on the capa	city of external batteries		
Long-run	Numbers		16 - 20 pcs	(Adjustable)		
Model	Charging Current (max.)	1A/2A/4	4A/6A (Adjustable, 6A is o	only available for 16 pcs ba	atteries)	
	Charging Voltage		273 VDC ± 1% (Base	ed on 20 pcs batteries)		
INDICATO	RS					
LCD Displa	ay	Load level, Batter	ry level, AC mode, Battery	mode, Bypass mode, and	d Fault indicators	
ALARM						
Battery Mo	ode		Sounding even	ery 4 seconds		
Low Batter	у		Sounding e	very second		
Overload		Sounding twice every second				
Fault			Continuous	sly sounding		
PHYSICAL						
Standard	Dimensions, D x W x H (mm)	369 x 190 x 688		442 x 190 x 688	T	
Model	Net Weight (kg)	61	74	66	76	
Long-run	Dimensions, D x W x H (mm)	369 x 19			90 x 318	
Model	Net Weight (kg)	12		16		
ENVIRONMENT						
	Running Humidity & Temperature 0 - 95%, RH (Non-condensing) @ 0 - 40°C			0.1		
Noise Level < 55 dB @ 1 meter < 58 dB @ 1 meter					@ 1 meter	
MANAGEMENT						
-	Smart RS-232 /USB Supports Windows® 2000/2003/XP/Vista/2008, Windows®7/8, Linux, Unix, and M					
Optional SNMP manager and web browser						
STANDARDS & CERTIFICATIONS						
Quality		ISO 9001 ; ISO 14001				
Complianc	mpliance EN62040-3, EN61000, EN62040-2, EN62040 -1, CE					

<sup>[1] -</sup> Derate to 60% of capacity in Frequency converter mode and to 90% when the output voltage is adjusted to 208 VAC.



SY-G reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on SY-G products previously or subsequently sold.



Empowering New Frontiers™